

# データマット対応表 RL78/G13

UM…フラッシュメモリ(ユーザーマット) UBM…ユーザーブートマット DF…データフラッシュ/EEPROM  
 ○…書き込み可能 ×…書き込み不可 WS…WS(サンプルマイコンで評価) ※製品版とは仕様が異なる場合がございます

マイコン名	FM-ONE			FLASHMATE5V1			FLASH2		
	UM	UBM	DF	UM	UBM	DF	UM	UBM	DF
R5F1006A	○	/	○	×	/	×	×	/	×
R5F1006C	○	/	○	×	/	×	×	/	×
R5F1006D	○	/	○	×	/	×	×	/	×
R5F1006E	○	/	○	×	/	×	×	/	×
R5F1007A	○	/	○	×	/	×	×	/	×
R5F1007C	○	/	○	×	/	×	×	/	×
R5F1007D	○	/	○	×	/	×	×	/	×
R5F1007E	○	/	○	×	/	×	×	/	×
R5F1008A	○	/	○	×	/	×	×	/	×
R5F1008C	○	/	○	×	/	×	×	/	×
R5F1008D	○	/	○	×	/	×	×	/	×
R5F1008E	○	/	○	×	/	×	×	/	×
R5F100AA	○	/	○	×	/	×	×	/	×
R5F100AC	○	/	○	×	/	×	×	/	×
R5F100AD	○	/	○	×	/	×	×	/	×
R5F100AE	○	/	○	×	/	×	×	/	×
R5F100AF	○	/	○	×	/	×	×	/	×
R5F100AG	○	/	○	×	/	×	×	/	×
R5F100BA	○	/	○	×	/	×	×	/	×
R5F100BC	○	/	○	×	/	×	×	/	×
R5F100BD	○	/	○	×	/	×	×	/	×
R5F100BE	○	/	○	×	/	×	×	/	×
R5F100BF	○	/	○	×	/	×	×	/	×
R5F100BG	○	/	○	×	/	×	×	/	×
R5F100CA	○	/	○	×	/	×	×	/	×
R5F100CC	○	/	○	×	/	×	×	/	×
R5F100CD	○	/	○	×	/	×	×	/	×
R5F100CE	○	/	○	×	/	×	×	/	×
R5F100CF	○	/	○	×	/	×	×	/	×
R5F100CG	○	/	○	×	/	×	×	/	×

次頁へ続く

RL78/G13 前頁つづき

UM…フラッシュメモリ(ユーザーマツト) UBM…ユーザーブツトマツト DF…データフラッシュ/EEPROM

○…書込み可能 ×…書込み不可 WS…WS(サンプルマイコンで評価) ※製品版とは仕様が異なる場合がございます

マイコン名	FM-ONE			FLASHMATE5V1			FLASH2		
	UM	UBM	DF	UM	UBM	DF	UM	UBM	DF
R5F100EA	○	/	○	×	/	×	×	/	×
R5F100EC	○	/	○	×	/	×	×	/	×
R5F100ED	○	/	○	×	/	×	×	/	×
R5F100EE	○	/	○	×	/	×	×	/	×
R5F100EF	○	/	○	×	/	×	×	/	×
R5F100EG	○	/	○	×	/	×	×	/	×
R5F100EH	○	/	○	×	/	×	×	/	×
R5F100FA	○	/	○	×	/	×	×	/	×
R5F100FC	○	/	○	×	/	×	×	/	×
R5F100FD	○	/	○	×	/	×	×	/	×
R5F100FE	○	/	○	×	/	×	×	/	×
R5F100FF	○	/	○	×	/	×	×	/	×
R5F100FG	○	/	○	×	/	×	×	/	×
R5F100FH	○	/	○	×	/	×	×	/	×
R5F100FJ	○	/	○	×	/	×	×	/	×
R5F100FK	○	/	○	×	/	×	×	/	×
R5F100FL	○	/	○	×	/	×	×	/	×
R5F100GA	○	/	○	×	/	×	×	/	×
R5F100GC	○	/	○	×	/	×	×	/	×
R5F100GD	○	/	○	×	/	×	×	/	×
R5F100GE	○	/	○	×	/	×	×	/	×
R5F100GF	○	/	○	×	/	×	×	/	×
R5F100GG	○	/	○	×	/	×	×	/	×
R5F100GH	○	/	○	×	/	×	×	/	×
R5F100GJ	○	/	○	×	/	×	×	/	×
R5F100GK	○	/	○	×	/	×	×	/	×
R5F100GL	○	/	○	×	/	×	×	/	×
R5F100JC	○	/	○	×	/	×	×	/	×
R5F100JD	○	/	○	×	/	×	×	/	×
R5F100JE	○	/	○	×	/	×	×	/	×
R5F100JF	○	/	○	×	/	×	×	/	×
R5F100JG	○	/	○	×	/	×	×	/	×
R5F100JH	○	/	○	×	/	×	×	/	×
R5F100JJ	○	/	○	×	/	×	×	/	×
R5F100JK	○	/	○	×	/	×	×	/	×
R5F100JL	○	/	○	×	/	×	×	/	×
R5F100LC	○	/	○	×	/	×	×	/	×
R5F100LD	○	/	○	×	/	×	×	/	×
R5F100LE	○	/	○	×	/	×	×	/	×
R5F100LF	○	/	○	×	/	×	×	/	×
R5F100LG	○	/	○	×	/	×	×	/	×
R5F100LH	○	/	○	×	/	×	×	/	×
R5F100LJ	○	/	○	×	/	×	×	/	×
R5F100LK	○	/	○	×	/	×	×	/	×
R5F100LL	○	/	○	×	/	×	×	/	×
R5F100MF	○	/	○	×	/	×	×	/	×
R5F100MG	○	/	○	×	/	×	×	/	×
R5F100MH	○	/	○	×	/	×	×	/	×
R5F100MJ	○	/	○	×	/	×	×	/	×
R5F100MK	○	/	○	×	/	×	×	/	×
R5F100ML	○	/	○	×	/	×	×	/	×
R5F100PF	○	/	○	×	/	×	×	/	×
R5F100PG	○	/	○	×	/	×	×	/	×
R5F100PH	○	/	○	×	/	×	×	/	×
R5F100PJ	○	/	○	×	/	×	×	/	×
R5F100PK	○	/	○	×	/	×	×	/	×
R5F100PL	○	/	○	×	/	×	×	/	×
R5F100SH	○	/	○	×	/	×	×	/	×
R5F100SJ	○	/	○	×	/	×	×	/	×
R5F100SK	○	/	○	×	/	×	×	/	×

RL78/G13 前頁つづき

UM…フラッシュメモリ(ユーザーマツト) UBM…ユーザーブツトマツト DF…データフラッシュ/EEPROM

○…書込み可能 ×…書込み不可 WS…WS(サンプルマイコンで評価) ※製品版とは仕様が異なる場合がございます

マイコン名	FM-ONE			FLASHMATE5V1			FLASH2		
	UM	UBM	DF	UM	UBM	DF	UM	UBM	DF
R5F100SL	○	/	○	×	/	×	×	/	×
R5F1016A	○	/	/	×	/	/	×	/	/
R5F1016C	○	/	/	×	/	/	×	/	/
R5F1016D	○	/	/	×	/	/	×	/	/
R5F1016E	○	/	/	×	/	/	×	/	/
R5F1017A	○	/	/	×	/	/	×	/	/
R5F1017C	○	/	/	×	/	/	×	/	/
R5F1017D	○	/	/	×	/	/	×	/	/
R5F1017E	○	/	/	×	/	/	×	/	/
R5F1018A	○	/	/	×	/	/	×	/	/
R5F1018C	○	/	/	×	/	/	×	/	/
R5F1018D	○	/	/	×	/	/	×	/	/
R5F1018E	○	/	/	×	/	/	×	/	/
R5F101AA	○	/	/	×	/	/	×	/	/
R5F101AC	○	/	/	×	/	/	×	/	/
R5F101AD	○	/	/	×	/	/	×	/	/
R5F101AE	○	/	/	×	/	/	×	/	/
R5F101AF	○	/	/	×	/	/	×	/	/
R5F101AG	○	/	/	×	/	/	×	/	/
R5F101BA	○	/	/	×	/	/	×	/	/
R5F101BC	○	/	/	×	/	/	×	/	/
R5F101BD	○	/	/	×	/	/	×	/	/
R5F101BE	○	/	/	×	/	/	×	/	/
R5F101BF	○	/	/	×	/	/	×	/	/
R5F101BG	○	/	/	×	/	/	×	/	/
R5F101CA	○	/	/	×	/	/	×	/	/
R5F101CC	○	/	/	×	/	/	×	/	/
R5F101CD	○	/	/	×	/	/	×	/	/
R5F101CE	○	/	/	×	/	/	×	/	/
R5F101CF	○	/	/	×	/	/	×	/	/
R5F101CG	○	/	/	×	/	/	×	/	/
R5F101EA	○	/	/	×	/	/	×	/	/
R5F101EC	○	/	/	×	/	/	×	/	/
R5F101ED	○	/	/	×	/	/	×	/	/
R5F101EE	○	/	/	×	/	/	×	/	/
R5F101EF	○	/	/	×	/	/	×	/	/
R5F101EG	○	/	/	×	/	/	×	/	/
R5F101EH	○	/	/	×	/	/	×	/	/
R5F101FA	○	/	/	×	/	/	×	/	/
R5F101FC	○	/	/	×	/	/	×	/	/
R5F101FD	○	/	/	×	/	/	×	/	/
R5F101FE	○	/	/	×	/	/	×	/	/
R5F101FF	○	/	/	×	/	/	×	/	/
R5F101FG	○	/	/	×	/	/	×	/	/
R5F101FH	○	/	/	×	/	/	×	/	/
R5F101FJ	○	/	/	×	/	/	×	/	/
R5F101FK	○	/	/	×	/	/	×	/	/
R5F101FL	○	/	/	×	/	/	×	/	/
R5F101GA	○	/	/	×	/	/	×	/	/
R5F101GC	○	/	/	×	/	/	×	/	/
R5F101GD	○	/	/	×	/	/	×	/	/
R5F101GE	○	/	/	×	/	/	×	/	/
R5F101GF	○	/	/	×	/	/	×	/	/
R5F101GG	○	/	/	×	/	/	×	/	/
R5F101GH	○	/	/	×	/	/	×	/	/
R5F101GJ	○	/	/	×	/	/	×	/	/
R5F101GK	○	/	/	×	/	/	×	/	/
R5F101GL	○	/	/	×	/	/	×	/	/
R5F101JC	○	/	/	×	/	/	×	/	/
R5F101JD	○	/	/	×	/	/	×	/	/

RL78/G13 前頁つづき

UM…フラッシュメモリ(ユーザーマツト) UBM…ユーザーブツトマツト DF…データフラッシュ/EEPROM

○…書込み可能 ×…書込み不可 WS…WS(サンプルマイコンで評価) ※製品版とは仕様が異なる場合がございます

マイコン名	FM-ONE			FLASHMATE5V1			FLASH2		
	UM	UBM	DF	UM	UBM	DF	UM	UBM	DF
R5F101JE	○	/	/	×	/	/	×	/	/
R5F101JF	○	/	/	×	/	/	×	/	/
R5F101JG	○	/	/	×	/	/	×	/	/
R5F101JH	○	/	/	×	/	/	×	/	/
R5F101JJ	○	/	/	×	/	/	×	/	/
R5F101JK	○	/	/	×	/	/	×	/	/
R5F101JL	○	/	/	×	/	/	×	/	/
R5F101LC	○	/	/	×	/	/	×	/	/
R5F101LD	○	/	/	×	/	/	×	/	/
R5F101LE	○	/	/	×	/	/	×	/	/
R5F101LF	○	/	/	×	/	/	×	/	/
R5F101LG	○	/	/	×	/	/	×	/	/
R5F101LH	○	/	/	×	/	/	×	/	/
R5F101LJ	○	/	/	×	/	/	×	/	/
R5F101LK	○	/	/	×	/	/	×	/	/
R5F101LL	○	/	/	×	/	/	×	/	/
R5F101MF	○	/	/	×	/	/	×	/	/
R5F101MG	○	/	/	×	/	/	×	/	/
R5F101MH	○	/	/	×	/	/	×	/	/
R5F101MJ	○	/	/	×	/	/	×	/	/
R5F101MK	○	/	/	×	/	/	×	/	/
R5F101ML	○	/	/	×	/	/	×	/	/
R5F101PF	○	/	/	×	/	/	×	/	/
R5F101PG	○	/	/	×	/	/	×	/	/
R5F101PH	○	/	/	×	/	/	×	/	/
R5F101PJ	○	/	/	×	/	/	×	/	/
R5F101PK	○	/	/	×	/	/	×	/	/
R5F101PL	○	/	/	×	/	/	×	/	/
R5F101SH	○	/	/	×	/	/	×	/	/
R5F101SJ	○	/	/	×	/	/	×	/	/
R5F101SK	○	/	/	×	/	/	×	/	/
R5F101SL	○	/	/	×	/	/	×	/	/